



StarFlash® Micro Signal Mirror



1. Stand facing the sun or other light source in an open area with a clear view of the sky and, if possible, the horizon.
2. Reflect light from the light source onto your hand or other nearby surface, making sure to not block the light from the light source to the mirror surface.

3. Slowly bring the mirror toward your eye until the mirror touches your cheek. Look through the star at the reflected light on your hand (or other surface). A bright glowing spot will show in the star. This is the aim indicator.

4. Holding the mirror close to your eye, and still looking at the aim indicator, slowly turn and angle the mirror until you "place" the aim indicator directly on the object you wish to flash. If no target is in sight, continually sweep the horizon.

Liquid-Filled Button Compass



While standing still and holding the compass in a horizontal position, allow the "N" arrow to point north. Make sure no large metal objects are in close proximity. Rotate compass slightly and repeat if you think you have an inaccurate reading.

KLIPP™ Biner Knife



A compact, durable knife and carabiner combo that is ergonomically designed for comfortable use. Can be attached to packs, purses, key rings, and other gear.

One-handed open and close.

Liner lock for added safety during use.

⚠ CAUTION: SHARP OBJECT

KEEP OUT OF REACH OF CHILDREN.

JetScream™ Micro Whistle



A powerful signaling device that can be heard above most natural and man-made noises.

To use, place lips around mouth hole and blow with force.

⚠ CAUTION:

This whistle is extremely loud.
 Intended for emergency use only

KEEP OUT OF REACH OF CHILDREN.

SEE-ME™ Light Stick



1. Tear foil pouch open and remove light stick.
2. Bend light stick in center until it snaps.
3. Shake vigorously.
4. After light is activated, do not bend stick.

Emergency Poncho



Numerous of uses in a survival situation: ground cloth, shelter, water collection, and more.

Keeps wearer dry and comfortable in rain.

⚠ WARNING:

To avoid danger of suffocation, keep plastic articles away from children. Do not use in cribs, carriages, or playpens.

Emergency Blanket



A compact, lightweight, and waterproof emergency blanket that can be used for heat deflection, body heat insulation, a wind and rain barrier, or an emergency signaling device.

Survival Towel



1. To expand towel for use, place in water.
2. Squeeze out excess water before use.
3. After use, rinse and hang to dry.

BrightForce™ Pico™



Batteries: 4 x LR41 replaceable
 Run Time: 15h

BATTERY CHANGE INSTRUCTIONS

1. Unscrew bezel and put aside.
2. Insert battery cartridge so arrow on cartridge points inward.

OPERATION

Screw bezel in until tight for "ON".
 Loosen slightly for "OFF".

Do not mix old and new batteries. Do not mix alkaline, standard, or rechargeable batteries.

⚠ WARNING:

CHOKING HAZARD - Small Parts.
 Not for children under 3 years.

⚠ CAUTION:

Do not look directly into the LED for more than a few seconds. Do not allow children to use LED light unless under the supervision of an adult.

Waterproof Matches



1. Hold the match firmly with your index finger and thumb.
2. Firmly press the match head to striker while simultaneously pulling the match quickly across the striker.

Store in a cool, dry place.

Close box or cover before striking.

Strike away from your body.

⚠ CAUTION:

KEEP OUT OF REACH OF CHILDREN.